

ASSEMBLY INSTRUCTION


Sonoma Dining Chair - Cushion Seat

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which have come loose inside the carton during shipment. Identify and count all parts and compare with the part list below. Place all wooden furniture parts on a clean and flat soft surface, such as carpet or rug to prevent from being scratched.

LIST OF PARTS


No	Description	Qty
1	Chair Back	1
2	Front Legs	1
3	Side Rail	2
4	Stretchers	2
5	Chair Seat	1

LIST OF PARTS


No	Description	Qty
A	JCBC 	6
B	Spring Washer 	6
C	Wood Screw (long) 	7
D	Allen Key 	1
E	Wood Dowel 	6
F	L-Bracket 	2
G	Wood Screw (short) 	4

WARNING
 -This Chair not suitable for Standing On
 -Do Not over Tighten the bolts and screw

1.





2.



ASSEMBLY INSTRUCTION

Sonoma Dining Chair - Cushion Seat

3.



4.

